



**Thank you for purchasing the Sunset Dimmer !**

Gradually dims a plugged in lamp over 30 minutes to off or night light mode. Just like the natural sunset

**Easy to Use**

- Plug Sunset Dimmer into a wall outlet
- Plug lamp into bottom of Sunset Dimmer
- Leave lamp turned on
- Press top button to start the Sunset Dimmer cycle
- Press bottom button to choose between "dim to off button out" or "dim to night light-button in" modes

Works with any lamp 75 Watts or less (incandescent or Halogen Bulbs), Device plugs into a normal 120VAC home power outlet. Extends Bulb Life !

Can be used for multiple uses around the house:

- Self timer for school programs that require a minimum of 20 minutes practice
- Help children that are afraid of the dark to gradually ease the transition to sleep.
- As a night light for safety
- Energy savings. Ensures lamp will not be left on overnight.

**Top Button**

The top Button will reset the lamp to full bright and restart the Sunset Dimmer cycle when pressed for a few seconds. If you do not want to return to the full bright state, you can quickly press the button to raise the light intensity. The sunset dimmer cycle will restart from that point.

**Bottom Button**

The bottom button is for "Dim to Off" or "Dim to Night Light" operation. When the button is in, the Sunset Dimmer is in "Dim to Night Light" mode. When the button is out, the Sunset Dimmer is in "Dim to Off" mode.

The bottom button can also be used as an on-off switch for the night light once the Sunset Dimmer has finished the dimmer cycle.

The Sunset Dimmer can be used on a wall outlet that is controlled by a wall switch. The Sunset Dimmer cycle can be restarted to "full bright" by turning the wall switch off for 2 seconds, and then turning it back on.

Visit [www.sunsetdimmer.com](http://www.sunsetdimmer.com) for additional information and tips  
Model SD2-3500 A product from G2 Product Solutions LLC